



Thermocouple selector switch TK

Thermocouple selector switch TK allow to switch stright thermocouples to the one output. We get readings or measurements of thermocouples connecting this output to indicator or measuring device. This selector switch can be used only with the measuring devices or indicators, which have possibility to extend outside sensor of cold junction compensation, for example TESTO 400.



Thermocouple selector switch TK versions according to the type and number of thermocouple:

- select K type thermocouples from 2, 4, ...16 thermocouples: TK-K-2, TK-K-4, ..., TK-K-16 ;
- select J type thermocouples from 2, 4, ...16 thermocouples: TK-J-2, TK-J-4, ..., TK-J-16

Other versions - on request.



AUREGIS UAB Savanoriu pr. 271/ Mituvos g. 2, Kaunas LT-50131

Tel./fax.: +370 37 313426 **Mob. :** (+370) 686 38409, 698 74609, 614 34419, 686 54049, 614 71784

E-mail: info@auregis.lt www.auregis.lt